


GTXImage CAD™ Series V28.5



Installation Guide

Version 28.5



Table of Contents

Table of Contents	Pg 2
Introduction	Pg 3
Product Overview	Pg 3
Installing GTXImage CAD or PLUS – Evaluation Copy	Pg 4
Uninstalling GTXImage CAD	Pg 7

GTXImage CAD™ Series V28.5

Installation Guide

Introduction

Thank you for your interest in the GTXImage CAD Series! This version is the latest Standalone 2D CAD software technology application from GTX Europe Ltd, which enables you to cleanup, manipulate raster and convert to vector entities, on all of your scanned paper drawings.

This guide has been produced to help you get the most out of your product as quickly as possible. This guide is not intended to be a full training manual, it is intended to give the basic commands to allow you to install and run the GTXImage CAD Series product.

Product Overview

The GTXImage CAD Series consists of two software products - GTXImage **CAD** & GTXImage CAD **PLUS**:

GTXImage CAD loads raster images and allows image clean-up, restoration & comprehensive editing.

GTXImage CAD PLUS provides the same functionality as GTXImage CAD, with the added capability to convert binary raster into AutoCAD vector entities & text.

Product Functionality.

Product Level	Product Functionality				
	Raster Cleanup	Raster Editing	CAD Drafting	R2V Conversion	ICR Text Conversion
GTXImage CAD	X	X	X		
GTXImage CAD PLUS	X	X	X	X	X

This demonstration version allows you to install an **Evaluation Copy** of **GTXImage CAD Series** products. This option allows you to experience the real capabilities of loading and working with scanned raster image files, including raster editing and raster conversion capabilities within GTX. It requires **no** additional software (such as AutoCAD) to run. The evaluation software allows you to use all the functionality except you cannot Save and Plot modified files. To evaluate the product to its full we suggest that you Install GTXImage CAD **PLUS** level product.

GTXImage CAD Evaluation Software - Installation

System Requirements

To install the GTXImage CAD evaluation software you will require the following minimum configuration:

CPU—Processor	Basic: 2.5–2.9 GHz processor Recommended: 3+ GHz processor
Operating System	Microsoft® Windows 11 & Windows 10 64 Bit
Drive space	Min 2Gb free hard disk space for installation
Memory	2 GB RAM (8GB Recommended)
Display	Conventional Displays: 1920 x 1080 with True Color High Resolution & 4K Displays: Resolutions up to 3840 x 2160 supported on Windows 10, 64 bit systems (with capable display card)
Display Cards	Basic: 1 GB GPU with 29 GB/s Bandwidth and DirectX 11 compliant Recommended: 4 GB GPU with 106 GB/s Bandwidth and DirectX 11 compliant

Installing the Software


***Important Note: Windows 11™ & Windows 10™ users must be logged in as “Administrator” in order to install GTXImage CAD Series. In addition, users should NOT install GTX software under the “Program Files” directory; instead we recommend that the Administrator install the GTX software in the local directory or your department's dedicated directory for 3rd party applications.**

1. Download the GTXImage CA Series V28 installer form the GTX.com web site.
[GTX](#)
2. Once downloaded, double click on the self extracting exe.
3. Setup will initialise and after a few seconds the opening dialog will appear.


Running the Install

This will start up the install wizard; it will start to prepare files to load the GTXImage CAD series programs.


Select **Next** in the install wizard to continue installing GTXImage CAD Series



You will be asked if you wish to accept the **GTX software license agreement**, if you agree select **I Accept** then **Next**.




You will now be asked to Configure the Destination Folder for the application or to accept the default, select **Install**.




You will be asked to select your chosen product level – GTXImage CAD or GTXImage CAD *PLUS*. To view the full capability of the Series select **GTXImage CAD PLUS**.

You will be asked to Install for metric or imperial Raster units, Select **appropriate measurement system** then **Next**.




SETUP will install the program files to your PC - It may take a few minutes.

When complete select **Finish**. A licencing dialog will be displayed & the installation is now complete.




To run GTXImage CAD simply double click on the **GTXImage CAD Series V28.5 Icon**.



Uninstalling the Software


To Uninstall simply go to **Start - Settings - Control Panel – Programs and Features – Image CAD Series V28.5** Install GTXImage CAD Series V28.5 again. You will be prompted to remove the product.

This will start the uninstall wizard. Upon running Uninstall, a dialog appears making sure you want to remove the application from your system. Click **Uninstall**.



While uninstalling a window will appear to show the progress of the uninstall.

When Uninstall wizard is complete, click **Finish** to exit.



**GTX Europe Ltd
Cams Hall, Cams Hill,
Fareham, Hants
PO16 8AB-UK
Email: info@gtxeurope.com
Phone: +44 (0) 1329 227455**

REMARKS:

GTX®, GTXRaster CAD®, GTXRaster CAD® PLUS and Intelligent Paper to CAD Solutions®, GTXImage CAD™, Intelligent Object Picking™ are registered trademarks of GTX Europe Ltd.

AutoClean™ & GTXScanClean™ are trademarks of GTX. U.S. Patent No. 7,016,536 applies.

Windows® is a registered trademark of Microsoft Corp.

AutoCAD® & Autodesk® are registered trademarks of Autodesk, Inc.

FLEXNet® is a registered trademark of Flexera™ Software.

FLEXENABLED™ is a trademark of Flexera™ Software.

CQuantizer © is copyright of Jeff Prosize 1996-1997

PDFLib V 10.1 & PDFLib TET 5.5 is a copyright of PDFlib GmbH.

All other brand names, product names, service marks or trademarks belong to their respective holders.

©Copyright GTX Europe Ltd 2025. All Rights Reserved.